



Procedure for upgrading Thrane IP Handset

1. Obtain the file “TT3672b_X_X_XXX.bin” from an appropriate source and save it on your local computer.
2. Connect and power your Fleet BroadBand or Explorer 727 UT to your PC as you normally would.
3. Connect the IP Handset to any of spare LAN port available on the terminal.
4. You will need to find out the IP address of the IP Handset, the IP address of the IP Handset can be found using the Handset as follows:
Menu > Status > Network Information.
5. Once you have found the IP address of the IP Handset, type the address into the web browser e.g. 192.168.0.x
6. From the web interface select UPLOAD FIRMWARE > BROWSER > find the firmware on your local computer as stated in step 1.
7. Press Upload Firmware




8. The next screen that appears will be the status of the firmware upgrade



9. You will now see the progress of the IP Handset firmware upgrade on the physical handset.



10. The Web interface will refresh the same window as step 8. Stating "*please wait while the handset restarts*"
11. Once restarted the web interface will refresh again and state the new firmware has been upgraded



12. Upgrade Complete